



.

	/	DL 1013M2	DL 1017R	DL 1017L	DL 1017C	DL 2101T13	DL 2109T02	DL 2109T03	DL 2109T04R	DL 2109T06	DL 2109T10	DL 2109T11	DL 2109T12	DL 2109T14	DL 2109T15	DL 2109T17	DL 2109T18	DL 2109T19	TL 2109TM	DL 2100	DL 1001
1	DC	1	1									1	3						1	1	
2	AC	1	1									1	3						1	1	
3	DC	1	1							1				1	3				1	1	
4	C	1	1							1				1	3				1	1	
5		1	1							1		1			1				1	1	
6		1	1						1		1			1					1	1	
7		1			1							1			1				1	1	
8	DC	1											1		1				1	1	
9		1	1	1	1	1							1		1	1			1	1	
10	(PF)	1	1	1	1	1							1		1		1		1	1	
11		1		1		1							1		1	1			1	1	
12		1	1	1	1	1	1			1			1		1	1			1	1	
13		1	1	1	1	1	1			1			1		1	2			1	1	
14	PF	1	1	1	1	1	1						1		1			1	1	1	
15	Four reading method	1	1	1	1	1	1			1			1		1	2			1	1	
16	6-	1	1					1					2		2				1	1	
		1	1	1	1	1	1	1	1	1	1	1	3	1	3	2	1	1	1	1	